



RANGEHOOD


MODEL RC90 - 90cm MODEL RC120 - 120cm MODEL RI90 - 90cm



















































































Dear Customer,

we would like to thank you and congratulate you on your choice.

This new product has been carefully designed and built using top quality materials, and meticulously tested to ensure that it meets all your culinary requirements.

Please read and observe these simple instructions, which will enable you to achieve excellent results from the very first time you use it. This state-of-the-art appliance comes to you with our very best wishes.

THE MANUFACTURER

THIS PRODUCT IS DESIGNED FOR DOMESTIC USE.

THE MANUFACTURER DECLINES ALL RESPONSIBILITY FOR DAMAGES TO THINGS OR PEOPLE DERIVING FROM INCORRECT INSTALLATION OR IMPROPER, ERRONEOUS OR UNSUITABLE USE.

THE APPLIANCE MUST NOT BE USED BY PEOPLE (INCLUDING CHILDREN) WITH PHYSICAL, SENSORIAL OR MENTAL IMPAIRMENTS, OR BY PEOPLE WITHOUT THE NECESSARY EXPERIENCE

OR KNOWLEDGE, UNLESS THEY ARE SUPERVISED OR INSTRUCTED IN THE USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY.

CHILDREN MUST BE SUPERVISED TO ENSURE THAT THEY DO NOT PLAY WITH THE APPLIANCE.

The hood may be installed in the filtering or in the ducting version.

Exhausting version (Fig.1) the hood aspirates the kitchen air saturated with fumes and odours, purifies it through the grease filters and expels it through an outlet pipe. With his version the charcoal filters are not required.

Filtering version (Fig.1A) the hood aspirates the kitchen air saturated with fumes and odours, purifies it through the grease filters and the charcoal filters and returns clean air into the room.

The charcoal filters are not supplied.

Decide from beginning on the type of installation.


For greater efficiency, we recommend to install the hood in exhausting version.

Let use gloves during installation and maintenance operations.

In case of exhausting version it is important:

- to prepare the hole and the duct of 150 mm.diameter
- to use a duct with the minimal indispensable length
- to use a duct with few curves as possible (max curve angle 90°)
- to avoid to use flat ducts or with different sections
- to use a duct with the smoother surface inside and of a certified material
- don't connect the hood to fumes exhaust ducts (fireplaces, boilers, stoves,...)
- the air can not be evacuated into a wall hole, if this hole is not dedicated to this purpose
- to equip the room of air intakes in order to not create air depression (it must not exceed the 0,04 mbar)

CONTROLS



- A) ON/ OFF motor (it switches the hood on the second speed)
- B) 1st motor speed
- C) 2nd motor speed
- D) 3rd motor speed
- E) 4th motor speed
- F) ON/OFF lamps: if pressed long, it permits to select 3 different levels. Last selected level will remain in memory when the cooker hood restarts. If the product is equipped with led lamps, it is not possible to select the different levels; therefore the function is only ON/ OFF.
- G) TIMER: it permits to select 3 several ranges(10', 15', 20' minutes)
- H) *Filter alarm
- I) Remote control signal receiver

*Filter alarm:

the first operation once you have connected the coke hood to the net, is to set it into exhausting or recycling mode. Proceed as follows:

once the cooker is connected all the keys will light for some seconds: press the key on/off for around 8 seconds until that the key H is not lighted. Press the key B if you want that the cooker hood works in exhausting mode (on this way the charcoal filters counter is not working because not considered); the red key H is blinking and you can confirm pressing it.

To set the coke hood into recycling mode (grease filters and charcoal filters counter) you must press the key C after the 8 seconds and the key H will be lighted red fix; pressing on it you can confirm. After 30 hours working, the key H will light fix: this means that it is time to clean the grease filters. After 140 hours working the key H will blink

red: this means that the grease filters must be cleaned and the charcoal filters replaced. To rest, press the key H longer for second 7-8.

Note well: it is not possible to reset partially the counter times until the system doesn't show one of the alarms. This means that intermediate resets are not possible.

REMOTE CONTROL FUNCTIONS (if available)



- A) ON/OFF motor (it switches the hood on the second speed)
- B) It decreases the motor's speed
- C) It increases the motor's speed
- D) ON/OFF lamps (it is possible to settle the lamps intensity only manually on the hood)

MAINTENANCE

Before cleaning and maintenance operations, would you please cut the power.

Cooker hood cleaning:

the cooker hood must be cleaned at least each 2 months in order to prevent the fire's risk; to clean the hood externally, a soft cloth moistened with warm water and neutral soap must be used for the painted cooker hoods and specific cleaning producs for the stainless steel cooker hoods.

To clean the cooker hood internally, use a cloth with denatured alcohol.

Do not use abrasive or corrosive products!

Grease filters cleaning(for exhausting and filtering executions)

Clean the grease filters at least each 2 months in order to prevent the fire's risk and anyway according the use of the appliance.

To remove the grease filters push on the filter's handle.


Wash them hand or in the dishwasher by using a neutral soap. Please take also into consideration that the dishwasher wash can altherate the grease filter's colour but not their feature.

Charcoal filters replacement (in case of filtering execution):

The charcoal filters must be replaced at least each 6 months in order to prevent fire's risk and anyway according the use of the appliance.

How to replace the charcoal filters:

Insert the charcoal filter in the special slots and then clip it (as shown in the picture)



Lamps replacement:



Remove the lamp glass gently with a screwdriver. Replace with a lamp of the same type. Do not touch the new lamp with bare hand.



Don't touch the lamps if they are still hot!

MALFUNCTION

Before to contact the Technical Service, please verify these simple cases:

Why the cooker hood is not working?

- is there power cut?
- Is the cooker hood switched off?
- Is the plug disconnected or damaged?

Why the cooker hood is inefficient?

- is the cooker hood working at the suitable speed to remove the quantity of the fumes and vapours?
- Is the kitchen room enough ventilated to permit an adeguate air intake?
- Must the grease filters be cleaned?
- Must the charcoal filters be replaced?(in case of filtering cooker hood)
- After 10 minutes continuous working at the 4th speed, the cooker hood goes automatically to the 2nd speed (normal working speed)

Why the cooker hood switched off while is working?

- Is there a sudden power cut?
- Is the plug disconnected or damaged?
- After 5 hours continuous working the cooker hood turns off automatically(energy saving).



Warranty Statement

This warranty is provided by:

Name:
Address:
14/24-32 Lexington Drive, Bella Vista
Telephone Number:
1300 FULGOR (1300 385 467)
Email Address:
contact@fulgor.com.au
Website:
www.fulgor.com.au

This Warranty is provided for the following Product: (please fill in details upon purchase)

Product Name:

Model Number:

Date of Purchase:

1. Warranty Period

1.1 Domestic Warranty

Fulgor Milano Australasia warrants that any Product purchased from it, and when used in accordance with the Instructions for household or personal use, shall be delivered free from defects in workmanship and materials and will perform for a period of two (2) years from the date of purchase.

1.2 Commercial Warranty

Fulgor Milano Australasia warrants that any Product purchased from it, and when used in accordance with the Instructions for Commercial Use, shall be delivered free from defects in workmanship and materials and will perform for a period of one (1) year from the date of purchase.

2. Exclusions from Warranty

2.1 This Warranty does not cover:

- i. Abuse;
- ii. Misuse;
- iii. Any damage sustained by a product whilst being transported;
- iv. Other defects not related to materials or workmanship;
- v. Consumable items including, but not limited to, replacement of light globes, glass breakage due to impact;
- vi. Damage or failure caused to the Product by unsuitable physical or operating environment.

3. Warranty Claim

3.1 To make a Claim you must:

- a) Contact your nearest Local Servicing Agent, details of which are on Fulgor Milano Australasia's website listed above; and
- b) Provide Proof of Purchase and this Warranty to the Local Servicing Agent.
- 3.2 Upon receipt of a valid Claim, a Local Servicing Agent will attend your premises to inspect the Product.
- 3.3 Where a Product is found to be defective, Fulgor Milano Australasia will, at its option and expense, repair or replace the Product or the defective material or part. If Fulgor Milano Australasia repairs or replaces a defective Product, the warranty period for any Product repaired or replaced does not extend beyond the original Warranty Period.
- 3.4 Where the Product is located outside the Normal Servicing Area, You must pay for the cost of the nearest Local Servicing Agent to attend your premises.

- **3.5** If You are unable to provide Proof of Purchase, Fulgor Milano Australasia will not be obliged to repair or replace the defective Product.
- **3.6** Fulgor Milano Australasia will not be responsible for any costs or expenses, loss or damage, associated with:
 - a) Any transport of the Product to a Local Servicing Agent;
 - b) Any consequential damages from the use of the Product;
 - c) The de-installation and re-installation of the Product at Your premises to make the Product available for inspection and servicing/repair, or any consequential damage caused by de-installation and re-installation of the Product.
- 3.7 You may assign this Warranty. An assignee of this Warranty may only make a Claim where the following conditions are met:
 - a) You have provided to the assignee, and the assignee produces, Your Proof of Purchase; and
 - b) Any claim by an assignee is made within the original Warranty Period.

4. Statutory and Other Legal Rights

- **4.1.** Your rights under this Warranty are in addition to and do not affect in any way any other rights or remedies that you have under any law which relates to the Product.
- **4.2.** Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

5. Definitions

"Claim" means a claim made under this Warranty.

"Commercial Use" means use that is not household or personal use;

"Fulgor Milano Australasia" means Fulgor Milano Australasia Pty Ltd ACN 164 163 982;

"Instructions" means any instructions provided by Fulgor Milano Australasia for the use of the Product;

"Local Servicing Agent" means a servicing agent which has been appointed by Fulgor Milano Australasia, to service a Product;

"Normal Servicing Area" means an area where a Local Servicing Agent has been appointed by Fulgor Milano Australasia to service Products;

"Product" means the product of Fulgor Milano Australasia that this Warranty applies to;

"Proof of Purchase" means the receipt issued to You at the point of sale;

"Warranty" means this warranty statement;

"Warranty Period" means the applicable warranty period depending on whether it is commercial warranty or domestic warranty;

"You" means you the purchaser of the Fulgor Milano Australasia Product.



1300 FULGOR - 1300 385 467 | contact@fulgor.com.au 14/24-32 Lexington Drive, Bella Vista, New South Wales 2153